



[FAQs](#) > [Technical FAQs](#) > [Set-up robot](#) > [Can I change the position of the docking station?](#)

Can I change the position of the docking station?

Sara - 2023-08-25 - Set-up robot

Yes. Simply place the docking station in another place within the same map. The robot will update the position of the docking station on the map during its next cleaning run.