юmу

FAQs > Technical FAQs > Get to know your robot > How do I adjust cleaning power?

How do I adjust cleaning power?

Sara - 2023-08-25 - Get to know your robot

You can adjust the cleaning power during the cleaning run by simply tapping on the icon. You can also set the cleaning power for each room via the map edit screen.