



[지식 베이스](#) > [Technical FAQs](#) > [Maintenance of the robot](#) > [How do I empty the dust bin?](#)

How do I empty the dust bin?

Sara - 2023-08-25 - Maintenance of the robot

To remove the dust bin, release it at the two grips on the top front and rear and lift the dust bin out.