



지식 베이스 > Technical FAQs > Maintenance of the robot > How do I change the dust bag?

How do I change the dust bag?

Sara - 2023-08-25 - Maintenance of the robot

- * open the lid and remove carefully the dust bag
- * replace the dust bag with a fresh one and close the lid