юmу

FAQs > Technical FAQs > App-Function > I don't want my robot to enter a certain room. What can I do?

I don't want my robot to enter a certain room. What can I do? Sara - 2023-08-25 - App-Function

You can define the room as a no-go room. On the Edit map screen, simply tap on the room and select No-go area.